
Toshiba Satellite A205-S4577 Battery Replacement

This guide shows the user how to remove the battery (located on the bottom of the laptop).


Written By: Cameron Howard



INTRODUCTION

This guide removes the battery from the laptop in order to replace or inspect the battery.

Step 1 — Battery



- Locate the two sliding locks indicated in the photo.
- Slide the right lock (labeled "1") to the right. It will remain in the unlocked position.
- Slide the left lock (labeled "2") to the left and hold it in place.

Step 2



- While holding the left lock, place your finger in the indentation next to the battery and lift the battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 06:17:43 AM.